



IKEA essential components


HØLTE

When you place your order with IKEA you can ask them to remove all the fronts, cover panels and plinths. But there are a few items you need to make sure are included in your order so your kitchen can be installed.




HØLTE





Order

Visit IKEA online to place
essential components order



HØLTE

IKEA ESSENTIAL COMPONENTS

HINGES

UTRASTA HINGE 153°

With built in damper for
doors with drawers behind
(#104.272.62)

UTRUSTA HINGE 95°

For fridge/freezer doors
(#202.046.47)

UTRUSTA HINGE 110°

With built in damper for doors
adjacent to a wall or other cabinetry
(#404.017.84)

UTRUSTA LIFT-UP HINGE WITH DAMPER FOR HORIZONTAL DOOR

Available in small and large
and black or white
#904.624.83 or #704.624.84

DOOR CONNECTOR (IF REQUIRED)

UTRUSTA CONNECTION FITTING

To connect two doors
(#303.669.17)

DISHWASHER SLIDING HINGE

BEHJÄLPLIG

For integrated none IKEA
dishwashers
(#604.923.49)

ADJUSTABLE LEGS

METOD LEGS

(#402.055.99)

SUSPENSION RAILS

METOD SUSPENSION RAIL

For installation of base,
wall and high cabinets
(#602.056.64)

PLUGS

VARIERA COVER CAP

STUDIO
07960 976 895
0207 041 6015

hello@holte.studio

Unit G05 Northside Studios
16-29 Andrews Road
London E8 4QF

Monday to Friday 9am-6pm
Saturday 10am-5pm

holte.studio

HØLTE